

HP0-205 Certification III

HP Supporting the Enterprise Modular Library

Practice Exam: HP0-205 Exams

Exam Number/Code: HP0-205

Exam Name: Supporting the Enterprise Modular Library

Questions and Answers: 64 Q&As

([Certification III](#))



Exam : [HP0-205](#)

"Supporting the Enterprise Modular Library", also known as HP0-205 exam, is a HP certification. With the complete collection of questions and answers, TestInside has assembled to take you through 64 Q&As to your HP0-205 Exam preparation. In the HP0-205 exam resources, you will cover every field and category in HP Certification helping to ready you for your successful HP Certification.

Quality and Value for the HP0-205 Exam TestInside Practice Exams for HP **Certification III** Certification HP0-205 are written to the highest standards of technical accuracy, using only certified subject matter experts and published authors for development.

TestInside provide the professional Q&A.

1. We offer free update service for three month.

After you purchase our product, we will offer free update in time for three month.

2. High quality and Value for the HP0-205 Exam.

HP0-205 simulation test questions, including the examination question and the answer, complete by our senior IT lecturers and the Certification III product experts, included the current newest HP0-205 examination questions.

3. 100% Guarantee to Pass Your Certification III exam and get your Certification III Certification.

If you do not pass the HP Certification HP0-205 exam (Supporting the Enterprise Modular Library) on your first attempt using our TestInside testing engine and pdf file, we will give you a FULL REFUND of your purchasing fee.

use TestInside HP0-205 Q&A ensure you pass the exam at your first try.

TestInside professional provide Certification III HP0-205 the newest Q&A, completely covers HP0-205 test original topic. With our complete Certification III resources, you will minimize your Certification III cost and be ready to pass your HP0-205 tests on Your First Try, 100% Money Back Guarantee included!

[HP HP0-205](#) Test belongs to one of the Certification III certified test, if needs to obtain the Certification III certificate, you also need to participate in other related test, the details you may visit the [Certification III](#) certified topic, in there, you will see all related Certification III certified subject of examination.

TestInside Testing Engine Features

Comprehensive questions and answers about HP0-205 exam

HP0-205 exam questions accompanied by exhibits

Verified Answers Researched by Industry Experts and almost 100% correct

HP0-205 exam questions updated on regular basis

Same type as the certification exams, HP0-205 exam preparation is in multiple-choice questions (MCQs).

Tested by multiple times before publishing

Try free HP0-205 exam demo before you decide to buy it in Test-Inside.com.

Note: This pdf demo do not include the question's picture.

Exam : HP HP0-205

Title : Supporting the Enterprise Modular Library

1. Which HP tool is used to measure sequential performance?

- A. Performance Analysis Tool
- B. TapePerf
- C. I/O Meter
- D. HPReadData

Answer: A

2. Where do you find information regarding backup performance in a SAN environment? Select TWO.

- A. SAN Design Guide
- B. EBS Design Guide
- C. EBS Compatability Matrix
- D. Performance Troubleshooting Guide
- E. EML E-Series User Guide

Answer: BD

3. Which option of Command View TL is used to collect configuration information and execute a Device Analysis test on the selected device or devices for an EML E-Series tape library?

- A. backup configuration
- B. get config
- C. report event logs
- D. generate support ticket

Answer: D

4. Which EML E-Series tape library FRU has a Command Line Interface port?

- A. interface controller card
- B. robotics controller card
- C. Interface Manager memory card
- D. Interface Manager card

Answer: D

5. When replacing a failed Ultrium tape drive in an EML E-Series tape library, the library ____.

- A. must be offline with no I/Os going to any other drives
- B. must be powered off before replacing the new drive
- C. automatically recognizes the new drive without rebooting
- D. must be rebooted to recognize the new drive

Answer: D

6. You are at a customer site to repair an EML E-Series tape library. What is the last thing you must do after replacing any defective parts?

- A. Identify the cause of the initial fault.
- B. Close the front and rear doors.
- C. Test the library functionality.
- D. Check the cabling.

Answer: C

7. When replacing a failed Interface Manager card in an EML E-Series tape library, what must you do to preserve the original configuration information?

- A. Save the configuration to floppy disk and recover the configuration using the serial Command Line Interface.
- B. Print the configuration to file and then restore using ftp.
- C. Backup the configuration and then restore it using Command View TL.
- D. Move the memory card from the old to the new Interface Manager card.

Answer: D

8. Which file factor does NOT affect performance of tape devices in a SAN environment?

- A. extension
- B. compressibility
- C. directory depth
- D. size (larger is better)

Answer: A

9. What is the most critical factor affecting performance at the disk subsystem during a backup?

- A. disk connection speed
- B. disk fragmentation
- C. tape feed speed
- D. compression ratio

Answer: B

10. Compared to an Ultrium 460 tape drive, the transfer rate for native data of an Ultrium 960 drive is ____.

- A. slightly lower
- B. approximately the same
- C. approximately 2 times higher
- D. more than 2.5 times higher

Answer: D

11. Which component of the EML E-Series tape library is located in the top cPCI slot in the library base module card cage?

- A. Interface Manager memory
- B. robotics controller
- C. interface controller
- D. Interface Manager

Answer: B

12. An EML E-Series tape library is powered on. Before opening the library front door, ____.

- A. operable robotics must be parked
- B. the library must be powered off
- C. the Operator Control Panel must indicate "service request"
- D. cartridges must be removed from the load ports

Answer: A

13. You are at a customer site to repair an EML E-Series tape library. What is the first thing to consider before replacing any defective parts?

- A. the part replacement procedure
- B. how the fault was caused
- C. customer site procedures
- D. firmware revision levels

Answer: C

14. Which HP software can be used to calculate the actual compression ratio of backup data?

- A. Performance Analysis Tool
- B. Library and Tape Tools
- C. I/OMETER
- D. DPMETERM

Answer: B

15. Excessive R/W-head wear due to tape repositioning is a result of not providing the correct _____.

- A. feed speed
- B. block size
- C. file size
- D. compression ratio

Answer: A

[More HP0-205 Information](#)

Related HP0-205 Exams

[HP0-S16](#) *Implementing HP BladeSystem*

[HP0-D04](#) *Planning and Designing HP Enterprise Solutions*

[HP0-J26](#) *Designing and Implementing HP SAN Solutions*

[HP0-P13](#) *Planning & Design of HP Integrity Server Solutions*

[HP0-M23](#) *HP Business Availability Center Foundation*

[HP0-918](#) *HP Storage Data Protector 6.0 Fundamentals for Windows*

[HP0-M28](#) *Implementing HP Asset Manager Software*

[HP0-S14](#) *Design & Implementation of HP SIM for ISS Solutions*

[HP0-920](#) *HP Storage Data Protector 6.0 Fundamentals for UNIX*

[HP0-265](#) *Servicing HP Color LaserJet MFP Printers, High-End*

[HP0-263](#) *Servicing HP Color LaserJet Printers, High-End*

[HP0-239](#) *Supporting the Modular Array(MA) Storage Family*

[HP0-084](#) *HP Integrity Server Multi-OS Installation&Deployment*

[HP0-266](#) *Servicing HP Monochrome LaserJet MFP Printers, High-End*

[HP0-205](#) *Supporting the Enterprise Modular Library*

[HP0-085](#) *Planning and Designing HP Superdome Server Solutions*

[HP0-071](#) *Storage Sub systems for Window NT*

[HP0-080](#) *HP Multi-User System Product T500/T600 Certification*

[HP0-286](#) *HP Openview Servicecenter 6.x*

[HP0-207](#) *Procurve Adaptive EDGE Fundamentals*

Other HP Exams

[HP0-087](#) [HP0-866](#) [HP0-095](#) [HP1-P44](#) [HP0-276](#) [HP0-S23](#) [HP0-S24](#) [HP0-450](#)

[HP0-W03](#) [HP0-J17](#) [HP2-B44](#) [HP0-M17](#) [HP0-733](#) [HP0-Y22](#) [HP0-J20](#) [HP0-069](#)

[HP0-821](#) [HP0-Y19](#) [HP0-M15](#) [HP3-C15](#)