

HP0-490 Certification I

HP HP BladeSystem p-Class Solutions I

Practice Exam: HP0-490 Exams

Exam Number/Code: HP0-490

Exam Name: HP BladeSystem p-Class Solutions I

Questions and Answers: 134 Q&As

([Certification I](#))



Exam : [HP0-490](#)

"HP BladeSystem p-Class Solutions I", also known as HP0-490 exam, is a HP certification. With the complete collection of questions and answers, TestInside has assembled to take you through 134 Q&As to your HP0-490 Exam preparation. In the HP0-490 exam resources, you will cover every field and category in HP Certification helping to ready you for your successful HP Certification.

Quality and Value for the HP0-490 Exam TestInside Practice Exams for HP **Certification I** Certification HP0-490 are written to the highest standards of technical accuracy, using only certified subject matter experts and published authors for development.

TestInside provide the professional Q&A.

1. We offer free update service for three month.

After you purchase our product, we will offer free update in time for three month.

2. High quality and Value for the HP0-490 Exam.

HP0-490 simulation test questions, including the examination question and the answer, complete by our senior IT lecturers and the Certification I product experts, included the current newest HP0-490 examination questions.

3. 100% Guarantee to Pass Your Certification I exam and get your Certification I Certification.

If you do not pass the HP Certification HP0-490 exam (HP BladeSystem p-Class Solutions I) on your first attempt using our TestInside testing engine and pdf file, we will give you a FULL REFUND of your purchasing fee.

use TestInside HP0-490 Q&A ensure you pass the exam at your first try.

TestInside professional provide Certification I HP0-490 the newest Q&A, completely covers HP0-490 test original topic. With our complete Certification I resources, you will minimize your Certification I cost and be ready to pass your HP0-490 tests on Your First Try, 100% Money Back Guarantee included!

[HP HP0-490](#) Test belongs to one of the Certification I certified test, if needs to obtain the Certification I certificate, you also need to participate in other related test, the details you may visit the [Certification I](#) certified topic, in there, you will see all related Certification I certified subject of examination.

TestInside Testing Engine Features

Comprehensive questions and answers about HP0-490 exam

HP0-490 exam questions accompanied by exhibits

Verified Answers Researched by Industry Experts and almost 100% correct

HP0-490 exam questions updated on regular basis

Same type as the certification exams, HP0-490 exam preparation is in multiple-choice questions (MCQs).

Tested by multiple times before publishing

Try free HP0-490 exam demo before you decide to buy it in Test-Inside.com.

Note: This pdf demo do not include the question's picture.

Exam : HP HP0-490

Title : HP BladeSystem p-Class Solutions I

1. A customer has ordered a 42U rack fully configured with HP BladeSystem components from an HP reseller. The blade equipment arrived at the customer site badly damaged. What went wrong?

- A. HP BladeSystem components may never be shipped preconfigured in a rack. They must be shipped individually and assembled on site.
- B. HP BladeSystem must be shipped pre-configured only by HP Factory Express, who installs the appropriate padding.
- C. The reseller failed to install the BL p-Class shipping brackets and obtain a shock pallet.
- D. HP does not support shipping pre-configured HP BladeSystem in a 42U rack.

Answer: C

2. Which blade servers require the blade server sleeve? Select TWO.

- A. ProLiant BL20p G3
- B. ProLiant BL45p
- C. ProLiant BL30p
- D. ProLiant BL25p
- E. ProLiant BL20p G2
- F. ProLiant BL40p
- G. ProLiant BL35p

Answer: CG

3. What is the function of the ProLiant BL p-Class Diagnostic Station?

- A. scans all major hardware components of a ProLiant BL p-Class blade server for failures
- B. powers on and enables communication with a single ProLiant BL p-Class blade server or an interconnect switch outside the rack environment
- C. diagnoses communication problems between the ProLiant BL p-Class blade servers, the supported interconnect switches, the blade server enclosure, and the power enclosure
- D. tests and diagnoses the functionality of either a ProLiant BL p-Class blade server or an interconnect switch

Answer: B

4. Which hardware components are provided to the individual blade servers by the HP BladeSystem infrastructure? Select THREE.

- A. power supplies
- B. disk drives
- C. host bus adapters
- D. network interface controllers
- E. network interconnects
- F. processors
- G. SAN interconnects

Answer: AEG

5. Click the Exhibit button.

Which label corresponds to the default PXE NIC of the connected blade server?

- A. 1

- B. 2
- C. 3
- D. 4
- E. 5

Answer: B

6. Which utility enables you to approximate the power and heat load per rack, and calculate the full environmental impact of racks with varying configurations and loads?

- A. Enterprise Configurator
- B. ProLiant BL p-Class Power Calculator
- C. Rack and Power Calculator
- D. Site Installation Preparation Utility

Answer: D

7. Which HP BladeSystem hardware component has a 1-year onsite support and warranty?

- A. power backplane
- B. power supplies
- C. blade server sleeve
- D. ATA drives
- E. SCSI drives

Answer: D

8. You insert two ProLiant BL35p blade servers into a blade server sleeve which you then connect to the Diagnostic Station. When you attempt to power on the blade servers only one turns on. Why?

- A. You used a single power supply in the Diagnostic Station instead of two.
- B. Only one ProLiant BL35p blade server can be powered at one time by the Diagnostic Station.
- C. The ProLiant BL35p blade servers are not supported with the Diagnostic Station.
- D. You only connected one power cable from the Diagnostic Station to the blade server sleeve.

Answer: B

9. Click the Exhibit button.

Which label identifies the blade server enclosure DC power input connector for Bus A?

- A. 3
- B. 5
- C. 13
- D. 16

Answer: B

10. You have a SAS-version of the ProLiant BL35p blade server. What must you do to enable Fibre Channel storage connectivity?

- A. Install the Fibre Channel mezzanine HBA card.
- B. Replace the four-port SAS HBA with the Fibre Channel pass-through board.
- C. Install the multi-function NIC which has the Fibre Channel HBA integrated.
- D. Use the ATA-version of the ProLiant BL35p to connect to the Fibre Channel storage.

Answer: D

11. How does the ProLiant BL45p blade server connect to Fibre Channel storage?

- A. using the Dual-Port Fibre Channel Mezzanine Card
- B. using a PCI-X based multi-function NIC that has the QLogic HBAs integrated
- C. using PCI-X based HBAs
- D. using the Ethernet pass-through board that has the QLogic HBAs integrated

Answer: A

12. Which dual-processor blade server is designed for compute density and maximum power efficiency?

- A. ProLiant BL25p
- B. ProLiant BL30p
- C. ProLiant BL35p
- D. ProLiant BL45p

Answer: C

13. Which ambient air direction is used by the HP BladeSystem for cooling?

- A. front-to-back
- B. back-to-front
- C. top-to-bottom
- D. bottom-to-top

Answer: A

14. You are diagnosing a problem with an HP BladeSystem infrastructure. Some of the blade servers do not power on and the hot-plug power supply fault LED is flashing amber. What is the cause of this problem?

- A. The current power consumption exceeds the available power capacity.
- B. The management modules are cabled incorrectly.
- C. The power enclosure management module has failed.
- D. The power supply backplane has failed.

Answer: A

15. You are upgrading a non-enhanced blade server enclosure to an enhanced blade server enclosure. Your non-enhanced blade server enclosure was configured for power redundancy. You want to continue having power redundancy with the enhanced blade server enclosure. In addition to the Blade Server Enclosure Upgrade Kit, what else must you obtain?

- A. an additional power enclosure with power supplies
- B. a power enclosure management module upgrade
- C. 3-phase UPS
- D. additional power supplies

Answer: A

16. What is Smart Cooling?

- A. an HP-patented cooling technology available with the enhanced blade server enclosure
- B. an HP-patented cooling technology available as an option for the HP 10000 series racks
- C. a feature of HP SIM 5.0 that is capable of monitoring the temperature inside the blade server enclosure and adjusting the cooling fan speed accordingly
- D. a tool produced by HP Labs that is used for thermal modeling and demonstrating the impact of server deployments in an enterprise data center

Answer: D

17. What happens if the management module fails in the non-enhanced blade server enclosure?

- A. All blade servers continue to operate normally and all blade server iLO access continues unaffected.
- B. All blade servers continue to operate normally and all blade server iLOs become accessible through the front I/O port only.
- C. All blade servers continue to operate normally but all blade server iLO access becomes limited to the first blade server only.
- D. All blade servers continue to operate normally but all blade server iLOs become unavailable until the management module is replaced.

Answer: A

18. What is the maximum number of blade servers that you can install in an HP BladeSystem p-Class blade server enclosure with enhanced backplanes?

- A. 8
- B. 12
- C. 16
- D. 20

Answer: C

19. You are diagnosing a problem with an HP BladeSystem infrastructure. The installed blade servers or interconnect switches do not power on but the power supply AC power LEDs are on. None of the fault LEDs are illuminated. You have ensured that the power enclosure is properly cabled and connected to the power outlets. What is the possible cause of this problem?

- A. The power bus bar circuit breakers are in the off position.
- B. The power enclosure circuit breakers are in the off position.
- C. The power zones are incorrectly set.
- D. The sides A and B of the power enclosure do not have an equal number of power supplies.

Answer: A

20. What is the primary difference between the non-enhanced ProLiant BL p-Class blade server enclosure and the enhanced ProLiant BL p-Class blade server enclosure?

- A. The enhanced blade server enclosure includes two additional bays for redundant network interconnects.
- B. The enhanced blade server enclosure aggregates blade server iLOs into a single port on the side B network interconnect.
- C. The enhanced blade server enclosure no longer requires use of the blade server sleeve for the ProLiant BL30p and BL35p blade servers.
- D. The enhanced blade server enclosure has a split power backplane and requires two power enclosures for power redundancy.

Answer: D

[More HP0-490 Information](#)

Related HP0-490 Exams

[HP0-M15](#) HP Quality Center 9.2 Software

[HP0-S18](#) Implementing HP ProLiant ML/DL Servers

[HP0-M16](#) HP Quick Test Professional 9.2 Software

[HP0-A01](#) HP-UX 11i v3 System Administration

[HP0-M18](#) HP LoadRunner Software

[HP0-M19](#) HP Virtual User Generator Software

[HP0-S19](#) Integrating and Managing HP ProLiant ML/DL in the Enterprise

[HP0-Y20](#) ProCurve Adaptive EDGE Fundamentals

[HP0-Y19](#) ProCurve Accelerated ASE Mobility

[HP0-J24](#) Designing and Implementing HP Enterprise Backup Solutions

[HP0-J15](#) HP StorageWorks MASE 2088 Delta Exam

[HP0-X02](#) Designing & Implementing HP Enterprise Backup Solutions

[HP0-063](#) LF PROFESSIONAL COLOR WORKFLOW MANAGEMENT

[HP0-J22](#) Designing HP StorageWorks Solutions

[HP0-S17](#) Integrating and Managing HP BladeSystem in the Enterprise

[HP0-M22](#) Implementing HP Service Manager Software

[HP0-Y21](#) ProCurve Core Competencies

[HP0-Y11](#) ProCurve Security 7.31

HP0-P10 HP Integrity Server Multi-OS Installation &Deployment

HP0-P17 HP-UX 11i v3 Security Administration

Other HP Exams

<u>HP0-M23</u>	<u>HP0-S19</u>	<u>HP0-821</u>	<u>HP0-P20</u>	<u>HP0-A17</u>	<u>HP0-761</u>	<u>HP0-685</u>	<u>HP0-Y16</u>
<u>HP0-390</u>	<u>HP0-J24</u>	<u>HP0-X01</u>	<u>HP0-173</u>	<u>HP0-M18</u>	<u>HP0-773</u>	<u>HP0-538</u>	<u>HP0-022</u>
<u>HP0-M28</u>	<u>HP0-205</u>	<u>HP0-J23</u>	<u>HP0-446</u>				